

Pro Vision Software Update Procedure

Follow these procedures to update the Pro Vision software from a version 1.9 or a 2.1 to the new 2.4 version and retain the user programmed settings.



Update procedure from version V2.1 to V2.4

- Step 1:** Download the software update files V2.1mig and PRO-V2_4 at www.cumberlandpoultry.com and save to a USB drive.
- Step 2:** Insert the USB drive with the saved files into the USB port in the Pro Vision
- Step 3:** Update the software to transitional version V2.1mig by selecting the V2.1mig file and press “**Update soft**”.
- Step 4:** Update the software to V2.4 version by selecting the PRO-V2_4 file and press “**Update Soft**”

After updating software from V2.1 to V2.4, verify these settings:

- Verify clock start and stop time.
- If using ‘clock loop feeding’ adjust the repetition value.
- For breeder mode only, adjust the skip day selection and run time.
- Verify High T° alarm setting and adjust T° compensation offset if using outdoor T° probe.

Update procedure from version V1.9 to V2.4

- Step 1:** Download the software update files PRO-V2_1, V2.1mig and PRO-V2_4 at www.cumberlandpoultry.com and save to a USB drive.
- Step 2:** Insert the USB drive with the saved files into the USB port in the Pro Vision
- Step 3:** Update the software to version V2.1 by selecting the PRO-V2_1 file And press “**Update Soft**”
- Step 4:** Update the software to transitional version V2.1 migration by selecting the V2.1mig file and press “**Update soft**”.
- Step 5:** Update the software to V2.4 version by selecting the PRO-V2_4 file and press “**Update Soft**”

After updating software from V1.9 to V2.4, verify these settings:

- Verify clock start and stop time.
- If using ‘clock loop feeding’ adjust the repetition value.
- For breeder mode only, adjust the skip day selection and run time.
- Verify High T° alarm setting and adjust T° compensation offset if using outdoor T° probe.