



These cones are designed to help alleviate the back pressure caused by prevailing winds. Winds can cause the fans to labor and lose efficiency at minimum ventilation settings. (See Figure 1.)





Figure 1 Kit (10-0055)

When installing the wind deflectors, just follow these easy steps. Use temporary clamps to hold the brackets in place. Using the below Chart, measure and drill mounting holes in the top of the hood and fasten the bracket with nuts and bolts provided. (See Figure 2.)



D = Diameter of fan opening.  
X = Distance between end of fan cone to the flange of wind deflector.

Figure 2

| Part # | D   | X     |
|--------|-----|-------|
| WDH-12 | 12" | 5.25" |
| WDH-14 | 14" | 5.00" |
| WDH-18 | 18" | 3.60" |
| WDH-24 | 24" | 4.80" |
| WDH-36 | 36" | 7.20" |

